

# TRYON RX

## STYLE AND PERFORMANCE

PRESCRIPTION  
FRAME

★ EXCELLENCE



TRYON



16 g

### SUPPLIED WITH

Hard case,  
microfibre cloth



### FRAME

• TR90/PC-TPR

### LENS MATERIAL AVAILABLE

• CR39  
• Polycarbonate

### OPTIONAL

Retainer strap  
Ref. RUSHKITS



- + WRAP-AROUND FRAME
- + CO-INJECTED PC/TPR TEMPLES
- + NON-SLIP ADJUSTABLE BRIDGE
- + FLEX 160° TEMPLES

**bolle**  
SAFETY

# TRYON RX

## STYLE AND PERFORMANCE

MODEL	REFERENCES	SIZE	FRAME MARKING	TEMPLE LENGTH
TRYON RX	TRYON	61-18	EN166 F C€	117 mm
Strap only (option)	RUSHKITS	-	-	-

### LENS MARKING

#### Polycarbonate lens:

**F.** Low energy impact, resists a 6 mm, 0.86 g ball at 45 m/s  
Maximum protection for glasses.

#### CR39 lens:

**S.** Extra strong, resists a 22 mm 43 g ball falling 1.30 m at 5,1 m/s.

### FRAME MARKING

**EN 166** : guaranteed minimum resistance of the protective eyewear against everyday risks including dropping the protective eyewear onto the ground, ageing by light exposure, exposure to heat or corrosion etc.

**F.** Low energy impact, resists a 6 mm, 0.86 g ball at 45 m/s  
Maximum protection for glasses.

€ European standard ☞ Manufacturer name

**Bollé safety product approval certificates to CE standards will be sent on request.**

### STANDARD ASSEMBLY RESTRICTIONS:

**Maximum sphere power:** +7/-6

**Maximum cylinder compared with sphere :** +/-5.

### CORRECTED BASE:

**Corrected base :** 8

### CLEANING AND STORAGE

**CLEANING** : The lenses should be cleaned regularly. Bollé Safety recommends only using the B-clean lens cleaning system.

**MAINTENANCE** : Pitted, scratched or damaged lenses must be replaced by replacing the complete product. If the frame is damaged also replace the complete product. After each use it is recommended to keep the spectacles or goggles in a microfiber pouch or rigid case.

**STORAGE** : All products must be stored in a dry and clean environment.

PACKAGING AND EAN13 CODE		
	TRYON	RUSHKITS
Per piece	3660740008291	3660740007546

CHARACTERISTICS	
LENS MATERIALS	CR39, Polycarbonate
TYPES OF CORRECTIONS AVAILABLE	Single vision - Progressive
FRAME MATERIALS	TR90/PC-TPR
STRAP	Nylon/15mm/Adjustable



18/03/2019

Europe Bollé Safety  
95 rue Louis Guérin  
69100 Villeurbanne - France  
Tél. : 00 33 (0) 4 78 85 23 64  
Fax : 00 33 (0) 4 78 85 28 56  
contact@bolle-safety.com

[bolle-safety.com](http://bolle-safety.com)

U.K. Bollé Safety  
Unit C83 - Barwell Business Park Leatherhead Road - Chessington  
Surrey - KT9 2NY  
Tél. : 00 44 (0)208 391 4700  
Fax : 00 44 (0)208 391 4733  
e-mail : [uk@bollebrands.com](mailto:uk@bollebrands.com)

**bolle**  
SAFETY